

Installing the "E-Z" Tensioning Tool

Getting Started



You will need a hammer, drill motor, 7/16" drill bit, and tape measure to complete this installation. Please remove the tension tool from the package and locate the Safety Bar. Remove the wing nuts from both bolts.

Step #1



Position the bar about 13 1/2" from the edge of the table that you wish to stretch from. Strike the bolt with the hammer to "mark" the positioning. Be sure to strike both sides of the safety bar.

Step #2



Using the 7/16" drill bit and motor, drill out both 'bolt marks' that you made using the Safety Bar and hammer. Drill completely through the table or board you are using as you will need to fasten a wing nut to the bolt.

Step #3



Set the height of the Safety Bar to 1 3/4" from the table top using the secondary nut and washer. Once you have set this close, it will not need to be adjusted. Make sure that the bolt passes through the table.

Step #4



Fasten the included wing nuts and washers to the bolt on the bottom of the table. Hand tighten them and check the bar for any movement. If there is movement, apply more torque to the wing nuts.

Step #5



Your Safety Bar is now mounted and your Tensioning Tool is ready for use. Remember to wear eye protection and follow the instructions for the correct type of Shur-Loc "E-Z" Frame that you are using.